

QUNDA®

Universal A/C Remote Control

KT-N858
2000 In 1**QUNDA®**

Brand	Model Code	Brand	Model Code
ALPIN	0252, 0253, 0764, 1277, 1789	LITTLE DUCK	0015-0020, 0530, 1043
AUCMA	0288-0296, 0462, 1313, 1998	LOREN-SEBO	0255, 0471, 0472, 0767
AUX	0297-0300, 0451, 0474, 0475, 0812, 1987	MACQUAY	0234-0237, 0465, 0746, 1773
BANSHEN	0264, 1288, 1800	MICOM	0415, 0927, 1951
BOERKA	0383, 0434, 0436, 0437, 1407, 1972	MIDEA	0260-0265, 0526, 1289, 1976
CARRIER	0203-0209, 0456-0458, 0482-0486, 0563-0565	MITSUBISHI	0001-0045, 0476-0479, 0522, 0523, 0568, 0582, 0582, 1502
CHANGHONG	0301-0308, 0813, 1843	NORITZ	0431, 1455
CHIGO	0379-0382, 0489, 0515, 1403, 1916	PANASONIC	0138-0154, 0483, 0490-0492, 0653, 1507
CHOFU	0184-0187, 1209, 1723	National	
CHUNLAN	0345-0350, 0450, 0453, 1373	PANDA	0378, 0890
CORONA	0155-0163, 0459, 1180, 1995	PHILCO	0210, 0211, 0487, 0488, 1746
CONROWA	0377, 1401, 1913	PROTON	0421-0423, 0933, 1958
CONSUL	0463, 0975	RAYBO	0362-0367, 1386, 1898
DAEWOO	0203-0209, 0406, 0715, 1942	ROWA	0369, 0438, 0439, 0494, 0527, 0531, 1393
DAIKIN	0171-0183, 0566, 0577, 0583, 0685, 1707	Sabro	0435, 0506-0508, 1018, 1971
DOCTOR	0221, 0449, 1245, 1985	SAIJO DENKI	0212-0215, 0724, 1750
DONGBAO	0355-0361, 1385, 1891	SAMPO	0424-0426, 1448, 1961
DONGXINBAO	0413, 0925, 1654	SAMSUNG	0188-0196, 0516, 0518, 0700, 1726
Electrolux	0216-0220, 0569, 1245, 1752	SANYO	0046-0095, 0558, 0529, 0530, 1582
FEDDERS	0498, 0499, 0528	SASUKI	0254, 0470, 0766, 1494
FRESTECH	0277, 0519, 0520, 0789	SHANGLING	0384-0388, 0444, 0445, 1980
FUJITSU	0127-0137, 0464, 0552-0554, 1152	SHANXING	0392, 0449, 1416, 1985
FUNAI	0430, 0481, 1505, 1966	SHARP	0096-0106, 0525, 0609, 1640
GALANZ	0371, 0372, 0521, 0883, 1908	SHENGFENG	0376, 0480, 1504, 1912
General	0128-0136, 0639, 0976, 1161	SHINCO	0351-0354, 0454-0456, 1887
GUQIAO	0244, 0291, 1268, 1827	SHUANGLU	0376, 0404-0407, 0480, 1941
GLEE	0398, 0399, 0910, 1935	SHUAIKANG	0288, 0800
GOLDSTAR	0201, 0466-0469, 0979, 1737	SONGGE	0428, 0429, 1453, 1964
GREE	0309-0316, 0482, 0512, 0513	SOVA	0409, 0410, 0921, 1434
HAIER	0266-0272, 0453-0455, 0778	SUMMER	0427, 1451
HISENSE	0332-0335, 0517, 0847, 1359, 1868	SUNDURG	0257, 0505, 1017, 1793
HITACHI	0118-0126, 0630, 1145	SWAN	0434, 0477, 0516, 0524, 0946
HUABAO	0336-0344, 1360, 1878	TADIRAN	0246-0251, 0758, 1275
HUAKE	0408, 0920, 1944	TATUNG	0419, 0420, 0932, 1955
HUAMEI	0402, 0460-0465, 1426, 1999	TCL	0273-0281, 0476, 0493, 0570, 0786, 1305
HUALING	0317-0325, 0452, 0964	TECO	0256, 0473-0475, 1792
HUIFENG	0370, 0882	TIANDI	0415, 1439
HUIKANG	0368, 0441-0443, 1392, 1979	TOSHIBA	0107-0117, 0479, 0561, 0562, 0489, 1001, 1643
HYUNDAI	0202, 0433, 0480, 1226, 1969	TRANE	0227-0232, 0739, 1768
JDC	0373, 0440, 0952, 1909	UNI-AIR	0222-0224, 0450, 0734, 1986
JIANGNAN	0432, 1456	Wan bao	0138-0152, 0666, 0995, 1177
JINDA	0414, 0926, 1950	WEILI	0393-0396, 0907, 1420, 1929
JINSONG	0389-0391, 0446-0448, 1984	Whirlpool	0164-0170, 0502, 0677, 1760
JOHSON	0245, 0492, 1269, 1516	WINIA	0481, 0550, 0993
KANGLI	0374, 0375, 1399, 1910	XILENG	0411, 0412, 0924, 1947
KELON	0282-0287, 0473, 0485-0488	XINLE	0400, 0401, 0913, 1425, 1936
KLIMATAIR	0225, 0226, 0452, 0737, 1761	YANGZI(YAIR)	0403, 0915
KOLIN	0416-0418, 1441, 1952	YINYAN	258, 259, 326-331, 0478, 0838
KONKA	0397, 0457-0459, 1933	YORK	0107, 0238-0243, 0573, 0750, 1266
LG	0197-0200, 0514, 1026, 1733	Zhen bao	0129-0137, 1151, 1488, 1664
LIANGYU	0233, 0451, 0745, 1257		



6 974246 330259

MADE IN CHINA
NO. K-E-00122**KT-N858**
2000 In 1
UNIVERSAL A/C
REMOTE
CONTROLLCD background
light display

Thermometer function

One-Key function

Clock function

Patent of code
setting-numeric
input directlyClock shift celsius
and fahrenheit directly

Control 99.99 percent of A/Cs in the world

QUNDA®**KT-N858** Universal A/C remote control user's Guide

Product Description

KT-N858 is a new product with the patent of code setting which is invented by our engineers. You can input the numeric keys (0-9) for the code required directly, visual and convenient, quick and efficient. It has clock accurate, timer on and off, room temperature display, conversions between Celsius and Fahrenheit degree, code memory and . So it is your best choice.

Please read this manual carefully before using, which will be a great help for you to use the remote control.

The remote control can be used after setting. Pull side cover of remote control down, put 2 AAA (VM-4, R03) batteries as per polar indicated on battery cabin.

Patent code set up

- Find out the codes from code table, there are many groups codes of each brand. Please try the first group, if it does not operate your equipment, try the second, and do it like this until the codes can operate your equipment. Ex: ALPIN, you can choose 0252, if it does not work, please try the 0253 etc.
- Press the "SEL" key, the code on LCD will flash. Enter the 4 digit code in turn. Ex: "0252", press the "0" key, "0" stop flashing, the last three numbers flashing, then press the "2" key, the last two numbers flashing, and press the "5" key, the last number flashing, finally press the last number "2", all of the 4 digit code "0252" stop flashing, code entry is now complete. The remote control confirms the code automatically, and you can use the numeric key normally. You can operate your air conditioner now.
- After the air conditioner on, try other function keys, if they do not work well, please choose the next group of code until all the functions can work. The remote control is 2000 codes in one, so it is invalid when the code greater than 1999.

Auto-search code setting

If you do not know the brand of your air conditioner, or if your brand is not listed in the code table, please operate as per following steps:

- Put the remote control aim at your air conditioner, press the "SEL" key for 5 seconds and then release, remote control is entering the auto-search status, emit the signal continuously, the code flashes and increases. While the air conditioner receives the signal, and send one buzzer, press any key to confirm.
- Try other function keys, if they do not work, repeat above steps until it is correct.

Using of one-key

Whether in summer or winter, when you need to use the air conditioner, just put the remote aim at your air conditioner and press the "one-key". Remote can judge it is summer or winter according to the current temperature. In summer, the temperature will be set in 26°C. In winter, the temperature will be set in 20°C. If you feel not comfortable of the temperature, you could use temp "+" or "-" adjust the temperature. Of course, the remote also has the functions of other remotes; you could use it as the original.

Clock set up

- Press the "clock" key, clock signal flashes.

- Press "time +/ time -" key, adjust to the current time.
- Press the "clock" key again, clock signal stop flashing, the time setting finishes. (If you do not press the "clock" key, it also finishes automatically after 15 seconds)

Timer on

- Press the "TMR ON" key, the time on LCD flashes
- Press "TIME +/-" key, adjust the time when you want to make the air conditioner turn on automatically
- Time on LCD will stop flash after 6 seconds. Setting is complete

Timer off

- Press the "TMR OFF" key, the time on LCD flashes
- Press "TIME +/-" key, adjust the time when you want to make the air conditioner turn off automatically
- Time on LCD will stop flash after 6 seconds. Setting is complete

NOTE

- If press the "TIMER ON" or "TIMER OFF" key twice, timer is cancel.
- After timer setting is finished, you should make the remote control's emit directly to your air conditioner's receiving location in available distance. If not, it can not work.
- If you want to watch the time of timer, you should press the "TIMER ON" or "TIMER OFF" key, the LCD will display the time of timer and after 6 seconds it will display current time.

Conversions between Celsius and Fahrenheit degree

Press the "C/F" key can convert the display between Fahrenheit and Celsius degree.

Attention

- If it is not used for a long time, remove the battery to avoid leakage liquid of the battery to damage the machine. When the LCD looks dim, please change batteries. (New and old batteries can not be used together) After the batteries are replaced every time, it is not necessary to set model code again.
- As usual the LCD only display the time when pressing model codes "Enter" key, you can find the code and it is showed on LCD. After 5 seconds it returns time.
- Check carefully that there is no remora between remote controller and Air conditioner when the time on/off doesn't work. Because the operation is effective only when the air conditioner receives the timer on/off signal from remote controller.
- The manufacturer keeps the right to change the parameter and function of product.

Technical Parameters

Controllable distance : Large than 8 meters
Power supply voltage: DC 3 V
Battery model: Battery AAA(UM-4, R03)×2
Dimension: L165mm×W55mm×D25mm
Weight: Approx100g(excl.the batteries)